

## What is Sizzle?

SIZZLE is a caustic-based detergent for cleaning hot-plates, grills and ovens.

### Key Benefits

- ✓ Attacks fats and grease
- ✓ Removes burnt-on foods
- ✓ Fast acting

## How Does It Work?

SIZZLE contains caustic potash to rapidly attack fats and burnt-on protein residues. The selected surfactants in the product disperse and emulsify fatty, oily, proteinaceous and carbon residues, allowing the surface to be rinsed clean after a light scrub.

## For Use On...

SIZZLE is designed for removing fat, grease, carbon and burnt-on food residues from ovens, grills, hotplates and deep fryers. SIZZLE is ideal for use in all kitchens as well as on outdoor barbecue hotplates and grills.

## Technical Data

### Properties



COLOUR – Transparent colourless liquid  
ODOUR – Faint solvent  
pH = 13.0 – 14.0

## Dangerous Goods Classification

SIZZLE is a Class 8 corrosive liquid.

U.N. No: 1719	CLASS: 8
PACK GRP: II	HAZCHEM: 2R

## Environmental Care

SIZZLE conforms with all statutory environmental requirements. It is based on effective ingredients selected to perform efficiently so there is no waste or damage. SIZZLE is non-flammable and biodegradable. SIZZLE containers will be cleaned and reused if returned to Agar Cleaning Systems Pty Ltd., significantly reducing plastic usage and waste. They can also be recycled.

## Quality

The design, manufacture and supply of all Agar chemical products is controlled by the Agar Quality Management System which is registered and externally audited by SAI Global as complying with the requirements of AS/NZS ISO 9001 "Quality Management Systems – Requirements".

First Certified: 30 April 1996 SAI Certificate No.: QEC7358

## Application

- WEAR SAFETY GLASSES & GLOVES when using SIZZLE.
- Apply SIZZLE by squirt bottle supplied by Agar. Do not use spray bottle.

### Ovens:

Preheat oven to 60°C then turn off. Apply neat SIZZLE onto surfaces and leave 5 minutes to activate. Loosen carbon residues with stiff brush or scraper. Wipe up dissolved solids with damp cloth then rinse thoroughly with clean water.

### Grills & Hotplates:

Turn hotplate off after use and allow to cool for 5 minutes. Surface should be warm but not at full heat. Scrape food residues off then apply neat SIZZLE. Leave wet to activate for 10-15 minutes. Scrub with brush, spatula or griddle pad then wipe clean with cloth. Rinse well with potable water. Brush surface with cooking oil.

### Deep Fryers:

Cool and drain cooking oil. Partly fill fryer with cold water and add SIZZLE at the rate of 40ml per litre of water. Fill fryer with water to the upper oil level and bring to boil. Simmer until the surface is clean. Brush any other greasy surrounding areas with the solution. Drain solution while adding cold water at the same time to reduce the shock of the temperature change. Finally, rinse with clean water to remove all of the solution.

- SIZZLE is excellent on steel, stainless steel and enamel surfaces.
- Do not apply to aluminium or painted surfaces.
- If squirted on aluminium by accident, rinse off thoroughly with water before it dries on the surface.

## Disposal Information

### I. Used solutions -

Used Solutions of SIZZLE should be poured into a drain or trough that leads to the sewer system or a septic tank. These systems have a method for treating and breaking down the waste. Used solutions of detergent should not be poured into stormwater drains or down driveways as these drains are designed for rainwater and ultimately lead to the local river system.



The Chemistry of Cleaning™

# SIZZLE

## Hot Plate, Grill & Oven Cleaner

### 2. Unused product

It is best to keep the product and use it up! If this is not possible, try to give it to someone who can use it. (Make sure the product is in its original, labelled container).

If there is no alternative but disposal, it is safe to pour modest quantities of this product down the drain (to sewer) with running water. Leave the cold tap running for a few moments afterwards as this dilutes the product and reduces the concentration in the wastewater.

Remember, do not mix different cleaning products together during disposal!

### 3. Empty packaging

#### Bottles and drums

Our 5L and 20L bottles and drums are made from HDPE (polyethylene) or PET which can be recycled. You can dispose of these containers via the kerbside collection program or other recycling system. SIZZLE containers will be cleaned and reused if returned to Agar Cleaning Systems Pty Ltd, significantly reducing plastic usage and waste.

#### Cardboard cartons

Used boxes should be flattened and recycled in OCC (old, corrugated cardboard) or mixed wastepaper recycling programs.

Available in: 5L

Agar Cleaning Systems maintains Safety Data Sheets (SDS) on all its products. These sheets contain information that you may need to protect your employees and customers against health or safety hazards associated with our product. Agar Cleaning Systems recommends that you obtain a copy of the respective SDS sheet prior to using this product. The information in the Product Data Sheet is based on data we believe to be reliable. It is offered in good faith, but without guarantee, as conditions and methods of use of our product are beyond our control.



**MELBOURNE**  
Agar Cleaning Systems P/L  
12-14 Cope Street  
Preston VIC 3072  
Ph: (03) 9480 3000

**ADELAIDE**  
Agar Cleaning Systems P/L  
Unit 1, 138-140 Ashley Street  
Underdale SA 5032  
Ph: (08) 8293 2020

**BRISBANE**  
Agar Cleaning Systems P/L  
Unit 5, 13 Murdoch Circuit  
Acacia Ridge QLD 4110  
Ph: (07) 3274 3438

**SYDNEY**  
Agar Cleaning Systems P/L  
Unit 3, 68-72 Asquith Street  
Silverwater NSW 2128  
Ph: (02) 9743 6020

**PERTH**  
Briskleen Supplies  
38 Mulgool Road  
Malaga WA 6090  
Ph: (08) 9249 4566